



## ENGLISH

- Disc mark blinks on the front display panel for several seconds to adjust the clock at every hour. The disc remaining time also appears for several seconds.
- When turning on the unit, the channel number selected before turning off the unit or used for adjusting the clock at every hour, appears on the front display panel.

## FRANÇAIS

- Un symbole de disque clignote sur le panneau d'affichage avant pendant quelques secondes pour le réglage de l'horloge à toutes les heures. Le temps restant du disque apparaît également pendant quelques secondes.
- À la mise sous tension de l'appareil, le numéro de canal sélectionné avant la mise hors tension de l'appareil ou utilisé pour régler l'horloge à toutes les heures apparaît sur le panneau d'affichage avant.