

ENGLISH Production manual for creating dramatic movies.

Data storage and data editing sections.~

Creating dramatic memories

This software program ensures that the pictures you took with your Everio will remain dramatic whenever you view them, and gives you the chance to make movies with emotions that cannot be found in any script. The role of director will, of course, fall to you!



Taking the movie

Storing your movie on computer

Watching the movie

Any inquires or questions regarding the editing and creation of DVDs should be addressed to CyberLink, Inquires can be made by telephone, FAX, or through the company homepage. For further details, please refer to SOFTWARE INSTRUCTION AND USB CONNECTION GUIDE.

Saving your movie to DVD

Saving your edited movie to DVD

Creating your story

Post production

●A wide range of helpful and detailed information concerning CyberLink DVD Solution can be found on our homepage: http://www2.cli.co.jp/products/ne/

●Data storage section I Storing your movie on computer



Details

Storing

your movie

on computer

Open "EVERIO SD" for

SD card.

movies contained on an


For Windows 2000

My Computer

🦸 start

Any movies you take should be quickly copied to your computer. Creating room in the Everio's hard disk clears up space for you to store your next great movie.

Method • First, create a folder* on your computer to hold your new movie, and give the folder a name. *To create a new folder, use the mouse to right click on the desired location and select "New" and then "Folder". Paste Shortcut Undo Rename Save As Scheme... Graphics Options Display Modes Colonia Connect crosoft Office Publisher Document **2** Switch the camera's power button to "Play" and connect the camera to the computer by using the USB cable provided. (For further details on connection methods, please refer to SOFTWARE INSTRUCTION AND USB CONNECTION GUIDE.) Open "EVERIO HDD" that contains the movie Select "My Computer" from the "start" menu. Opening "EVERIO HDD"




For Windows XP

Opening "EVERIO HDD" After connecting the camera to the computer with the USB cable, a window entitled "EVERI-O HDD" will automatically appear.

> After selecting and clicking "OK" "Use Internet Explorer to display openedfiles", "EVERIO_HDD" on the hard disk will open.





1 Move the mouse cursor to the desired location while holding down the left mouse

*2 "SD VIDEO" folder stores regular movie data. "EXTMOV" folder stores unfinished movie data that failed to be produced.

Software installation

View movies that have been backed up

■ Start the installed "PowerDVD 5 NE" software.

manual.)

The appropriate software is required for stor-

ing or editing your movie on DVD by your

refer to the Install Section in the instruction


computer. (For further details regarding this,



② Click and select "Open media files"




3 Select the folder where the movie was saved from the list.



movie files for playback (files with the MOD extension, such as MOV001.MOD)


②Select the movie file (PRG001, PRG002 etc) from within the folder and click "Select All".




●Data storage section II Saving your movie on a DVD



All movies you make should be backed up on a DVD disc.






Select the backed up movie folders

Folder" screen.

(PRG001, PRG002 etc) from the "Browse for







Click Movie

After clicking "Movie", the movies will play as arranged upon clicking on









Click Produce

Saving an unedited movie

in its original picture quality

Movies taken using "Ultraf-

ine (U)", "Fine (F)", or "N-

ormal (N)", modes should

tv): movies shot with "E

conomy (E)", mode should


use NTSC DVD (extended



3 From the options on output format, select "DVD format".

4 Check the box, "After production, make disk in Power Producer"

6 Click "Next".




use NTSC DVD (high Quali- | 6 Click "Start" after confirming the save location.



Saving an edited movie in original picture quality • Upon finishing the production, "PowerProducer 3 Check the box, "Use SVRT" NE "will launch automatically. (Go to [Storing data on a DVD] 1)

• After arranging the movie in Time line, click on Storing data

on a DVD





3 Insert a writeable DVD into the drive.

4 Set the number of discs to be recorded in the "Final Output" window.

6 Data will start transferring to the DVD when



Options available


Plav Disk: Plavback of the recorded disc will begin automatically.


☐Go to Main window: Returns to the Power Producer Main Menu.


□Ouit PowerProducer: Exits the program.


6 Make your choice from the window that appears after recording is complete. (*)











Pressing 🔀 allows you to watch the movie on full-screen.

• Additional information

For users wishing to view their edited movie with their own video camera, it is possible to copy the edited pictures to their camera and view them on the go. Take full advantage of these features on the road.

For further information, please refer t SOFTWARE INSTRUCTION AND USB

Even without using a computer, it is als

possible to edit movies by using the cam-

cameras is in their ability to function as a

mini-editing suite, allowing basic editing

functions such as erasing unwanted mov-

ies and rearranging selected pictures. The

edited data can be copied to your comput-

er at a later date.

era directly. The advantage of using Everic

cedure during the editing process. For Further information, please refer to "U sers Guide" of the provided software.

Users who wish to enter postproduction

dubbing and background music can import these by using the time effects input pro-

CONNECTION GUIDE.

Completed DVDs can also be stored in your home DVD recorder by simply using the enclosed S/AV cable.

For further information, please refer to IN-TRUCTION MANUAL,

For further information, please refer to INSTRUCTION MANUAL

0206FOH-BS-VM