

JVC



Home Docking Kit


SIRIUS
SATELLITE RADIO



KS-K6013



INSTALLATIONS



LVT1263-001B
[J]

INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the manufacturer for compliance could void the user's authority to operate the equipment.

Safety Precautions



CAUTION:

Take the following precautions to keep the unit in proper working order:

- Installation must be performed according to this installation manual. JVC is not responsible for issues arising from incorrect installations.
- Use only the included power supply.
- Do not install the unit where it will be exposed to high levels of humidity, moisture, or dust.

NOTE: Use of the included antenna inside a home requires placement at a North-, West-, or East-facing window (depending on where you live). If a proper window location is not available, the antenna must be placed outside the home, away from any overhead obstructions.

Box Contents

After you unpack your Home Docking Kit, make sure everything listed below is included:

Home Docking Cradle



SIRIUS Antenna



Power Supply



Audio Cord



For the latest information about this and other JVC PnP products, visit the JVC Web site at <<http://www.jvc.com>>. If anything is missing or damaged, or if your Home Docking Kit fails to operate, notify your dealer immediately. It is recommended that you keep the original packaging in case you need to ship your Home Docking Kit in the future.

Installation in a Home




CAUTION:

Do not put JVC PnP in the home docking cradle until you have completed the installation.

1 Plug the audio cord's mini connector into the back of the cradle—AUDIO.

- When using the optional speaker (CS-SR100), plug the speaker input cord's mini connector into the back of the cradle—AUDIO. Then go to step 3.



Note: The FM OUT jack on the back of the cradle has no function. Do not plug any connector into the FM OUT jack in the following steps.

You can also use FM signal transmitter to output the sound of JVC PnP to your FM tuner. When you use this function, see “④ FM Transmitter Options” on page 24 of KT-SR2000 Instructions or “② FM Transmitter” on page 27 of KT-SR3000 Instructions.




CAUTION:

Do not plug the AC cord into a wall outlet until you have completed the installation.

- 2** Plug the audio cord's white (L ch) and red (R ch) connectors into your audio system.




- 3** Plug the power supply into the back of the cradle—DC 12 V.



Continued on the next page...


Installation in a Home (Continued)

- 4** Plug the antenna into the back of the cradle—ANT. until it is firmly secured.



- 5** Place the antenna near a window.

- Use the map on the next page as a general placement guideline—some experimentation may be needed to obtain the best results.




SIRIUS Satellite map

Due to the paths of SIRIUS satellites over the US, the best location for the antenna in your home depends on where you live. Use the map on the right column as a general placement guideline. See also “⑧ Antenna Aiming” on page 27 of KT-SR2000 Instructions or “⑩ Antenna Aiming” on page 31 of KT-SR3000 Instructions.

In major US cities, you may also be able to receive the signal from SIRIUS terrestrial repeaters, which may allow you to place the antenna away from a window. In all cases, since the antenna is weatherproof you can also locate it outside if necessary, clear of any overhead obstructions. (This is especially important if your house has an extended roof or extended window frame structures.)

- Area **1**: Place the antenna at an EAST-facing window.
- Area **2**: Place the antenna OUTSIDE, away from any overhead obstructions.
- Area **3**: Place the antenna at a WEST-facing window.
- Area **4**: Place the antenna at a NORTH- or EAST-facing window.
- Area **5**: Place the antenna at a NORTH-facing window.
- Area **6**: Place the antenna at a WEST- or NORTH-facing window.



Having TROUBLE with operation?

USA ONLY

Call 1-800-252-5722

<http://www.jvc.com>

We can help you!

JVC



EN

© 2005 Victor Company of Japan, Limited

© 2005 SIRIUS Satellite Radio Inc. "SIRIUS" and the SIRIUS dog logo are registered trademarks of SIRIUS Satellite Radio Inc.

0705MNMMDWKRI