


## How To Create DVDs simply

ENGLISH

**1** Install CyberLink DVD Solution. For details, Refer to "SOFTWARE INSTALLATION AND USB CONNECTION GUIDE".

**2** Connect the camera to the PC with the USB cable, or remove the removable hard disk from the camera and connect it to the PC using the card reader. Copy the video file folder (ex. "PRG001") in the recording medium to the PC.




**3** Start PowerDirector Express NE and click [Folder] of the import button, then select the folder copied to PC in step **2** to register it to the library.




**4** Drag and drop the videos from the library to the timeline/storyboard in the playback order.

If necessary, edit transition or title on the timeline/storyboard.

Click [Produce] button after finish editing.



(Example of transition)




**5** Select [Produce a Disc], and then click the [Next] button.



**6** Select the [DVD Format] and click [Next] button.

- If the video is [ULTRA FINE], [FINE], or [NORMAL], select [High Quality NTSC (or PAL) DVD]. If the video is [ECONOMY], select [Long Play NTSC (or PAL) DVD]. Encoding is not performed on unedited video, and high-speed processing is performed at the original image quality.
- Insert a check mark for [Use SVRT to save rendering time]. The minimum required encoding is performed, and high-speed processing is performed while keeping the original image quality. Insert a check mark for [After production, make disc inPowerProducer].




**7** Click the [Start] button to create the file. PowerProducer 2 Gold NE starts automatically.

**8** Load a blank DVD media into the recordable DVD drive.




**9** Click the [→] button in the [Import/Capture Content] screen of PowerProducer 2 Gold NE.



**10** Remove the check mark for [Include Menu] in the [Preview] screen, and then click the [→] button.



**11** Insert a check mark for [Burn to disc] in the [Final Output] screen, and then click the [Burn] button to create the DVD-Video.



For "Create DVD without title" and "Create DVD with title", refer to the instruction sheet "Creating DVDs and Writing Video Files Back to Camera".

For more details for creating a DVDs, refer to the user's guide of PowerDirector and PowerProducer installed on the PC. (Refer to the page 16 of "SOFTWARE INSTALLATION AND USB CONNECTION GUIDE".