

## Basic Connections

The connections as illustrated on page 19 of the instruction manual is incorrect. Please connect as shown below.

