



Model: XV-N670B / XV-N672S  
XV-N470B / XV-N472S  
XV-N370B / XV-N372S

## Information Sheet

- When the POWER is turned on for the first time, the unit need to set the menu language. Follow the descriptions below after the display connections.



1. Press POWER to turn the unit on. The language setup menu will appear on the screen.
2. Use ◀ / ▶ / ▲ / ▼ to select a language then press ENTER. The confirm menu will appear.
3. Use ◀ / ▶ to select the [Enter] then press ENTER to finish the language setup.

### Tip:

You can change the menu language to the others on the Setup menu.  
(See page 12 or 13 on the Instruction booklet.)