

JVC

Model: XV-BP1

Information Sheet

Depending on internet environment or disc that you are using, the system function may not be stable.

- When using BD-LIVE function, be sure to use USB Flash Drive with enough storage (1GB or more).
- When the system does not start BD-LIVE function, press STOP button and then erase the data of the USB Flash Drive.
- When the system does not function at all, unplug the power cord and then plug the power cord again after more than five seconds.

LVT2030-001A
P/N: MBM39302150