Model: XV-N680B / XV-N682S



Information Sheet

■ When the POWER is turned on for the first time, the unit need to set the menu language. Follow the descriptions below after the display connections.

×.				
	-			
	English	Percent		
	110.00			
	Frank St.	1.000		
	and the second	100	-	
	Real Logo	(Laterant)		
100 A	Contraction of the local division of the loc	_11930. 		
	Roman and Street			
	parents.	30	100	

- 1. Press POWER to turn the unit on. The language setup menu will appear on the screen.
- 2. Use ◀ / ► / ▲ / ▼ to select a language then press ENTER. The confirm menu will appear.
- 3. Use ◀ / ► to select the [Enter] then press ENTER to finish the language setup.

Tip:

You can change the menu language to the others on the Setup menu. (See page 12 or 13 on the Instruction booklet.)

> LVT2025-001A P/N: MBM39302143