



JVC Customer Care Center
1-800-252-5722

DR-MV7S Quick Guide FAQ's

Thank you for your purchase of the JVC DR-MV7S VHS/DVD Player/Recorder.

If you have any questions regarding the hookup or operation of your DR-MV7S, please contact our **Customer Care Center at 1-800-252-5722.**

Please Note:

Be sure to connect the AC power plug into the power outlet after all other connections are completed.

What DVDs can I use to record on my DR-MV7S?

- DVD-R, DVD+R, DVD-RW and DVD+RW can be used to record on your DR-MV7S.
DVD-RAM will not be recognized as recordable media on your DR-MV7S.

The Clock on my DR-MV7S is not setting automatically. I am not using a cable box. Is this a malfunction?

The default setting is Auto Clock: OFF.

- Change the setting to ON (Auto) by following the instructions on page 20 of your owner's manual.

The clock on your DR-MV7S may not set automatically in some geographical areas.

- If the clock does not set automatically even when the Auto Clock is set ON (Auto), you may set the clock manually by following the instructions on page 21 of your owner's manual.

Remote control unit does not work. Timer Recording does not work.

When the power to your DR-MV7S is interrupted by power outage or by disconnecting AC Plug;

- The remote control code of the main unit defaults to "C" code.
- The date and time information will be lost. If the Auto Clock setting is ON (Auto), the clock time will be automatically updated when broadcast signal is available.
- If you have programmed timer recording, that data will be lost and needs to be reprogrammed.
 - Perform the setting again by referring to each relevant page of owners manual.
Remote control code setting: page 24
Clock setting: page 20
Timer recording setting: page 37

For additional troubleshooting tips please refer to pages 51-53 in your owners manual.

When I turn on my DR-MV7S it flashes "Hello" and all the buttons on the remote control and the front panel will not respond for 10 - 15 seconds. Is this normal?

When your DR-MV7S is first turned on, it will flash "Hello" as the internal EPROM chip is updated with information.

- Please wait until "Hello" stops flashing before you attempt to use the remote control or front panel buttons. It takes 25-30 seconds until the set can be operated when a disk is on the tray.

My DR-MV7S is showing a distorted picture.

Your DR-MV7S has a progressive scan feature. This feature only works with a TV that accepts a progressive scan signal.

- If the picture is distorted, press OUTPUT STATUS button and select 480i.

My DR-MV7S is showing no picture.

There is no signal output other than HDMI when HDMI is connected and 720p/1080i is selected at OUTPUT STATUS.

- Press OUTPUT STATUS button and select either 480i or 480p in order to watch the video signal from AV OUT, S-VIDEO OUT, COMPONENT/PROGRESSIVE SCAN VIDEO OUT.

My newly recorded DVD plays in my DR-MV7S but does not play in other DVD players.

- You must "Finalize" the DVD before it can play in another DVD player.
Please see page 23 in your owner's manual.